# Scan QR code payment desktop **Scanner Sinple Guide**





#### version:01

# **Scanner Settings**

#### **System Settings**



Restore



Version

### **Interface Settings**



USB

#### **Sensitivity Setting**











Extra High

#### **Volume Settings**





Level 1(Lowest)

Level 2





Level 3(Default)

Level 4(Highest)

#### Virtual Keyboard Settings

After enabling the virtual keyboard in the Windows, the correct data can be output in any keyboard language. However, a certain output efficiency will be lost. Note that when using the virtual keyboard, user must ensure that the key of NumLock is enabled on the keyboard.





Virtual Keyboard Standard Keyboard

#### Fill Light Settings

- On while scanning: the fill light is on when the scan module working, and it goes out at other times.
- Always on: The fill light will continue to glow after the scan module is turned on.
- Always off: The fill light will not turn on under any circumstances..



Light on while scanning



Light always on



Light always off

#### **Sound Settings**





On

Off

#### **End Characters**







Add Carriage Return



Add Tab



Add Line Feed

Disable All Code Types

#### Readable Barcode Type

Users can read the following setting codes to enable/disable reading all symbologies and enable the default supported symbologies. After disable all symbologies, only setting codes are allowed to be read.



**Enable All Code Types** 



Default

## **Enhanced Decoding Settings**

After the Enhanced Decoding is enabled, the ability to read special codes such as stained bar codes and QR code on curved surfaces can be improved. Disable Enhanced Decoding will increase the decoding speed.





Enable Enhanced Decoding Disable Enhanced Decoding

#### Output Data Encoding Format

Set the output format by scanning the following setting codes to enable the scan module to output Chinese data in accordance with the specified encoding format. Note: GBK format is used for Notepad, and UNICODE format is used for Word and common chat tool input boxes. Original data output, serial port output for encrypted data.



Data Encoding Format (GBK)



Data Encoding Format (Original)



Data Encoding Format (UTF8)



Data Encoding Format (UNICODE)

## **□.** NFC Function Settings (Optional)

#### **NFC Function Settings**

In the Continuous Mode, the content output of the card number is controlled by the following setting codes.



\*Reverse Output



\*Hexadecimal



\*Decimal Output (Not filled with 10 digits)



\*Decimal Output



\*Decimal Output (Filled with 10 digits)

Use the following setting codes to control whether the 8-bit or 32-bit code content output is 0. Set the scan code output to 0, and the scan code result is 000000000.



\*8-bit/32-bit code (Output is not 0)



\*8-bit/32-bit code (Output is 0)

#### **NFC End Characters**



\*Turn Off End Character (Reading card)



\*Add TAB (Reading card)



\*Add Carriage Return (Reading card)



\*Add Carriage Return and TAB (Reading card)

#### Disclaimer

The company does not assume any responsibility for losses caused by natural disasters (such as earthquakes, floods, etc.) that exceed our ability to act.

The company is not responsible for any product liability associated with or arising from the application or use of any product, circuit, or other application described herein. About the system, equipment, machinery, materials, methods or processes that may be used in this product, or any combination with this product, the company does not express, imply, estoppel permission in any other means in connection with a patent or patent. The company only provides implied licenses for the equipment, circuits and subsystems included in its products.

The company does not assume any responsibility for the loss caused by improper use of communication hardware or software not specified.

The company does not assume any form of guarantee and technical support responsibility for third-party software used by this product.